



Panel after cleaning, before sanding.



Sanding the panel to prep for shellac coating.



First application of clear shellac.



Left: Post shellac application. Right: Comparison between the two panels.



Professor Abraham takes a seat on the train.